KIMO INSTRUMENTS

Technical Data Sheet

Pressure / Temperature / Humidity / Air Velocity / Airflow / Sound level

CO_2 stats

CO2ST-S


CE


KEY POINTS

- Range from 0 to 5000 ppm
- RCR relay output 3A/230 Vac, power supply 24 Vac/Vdc
- Visual and audible alarm, red led in front
- ABS V0 IP20 housing
- "¼ turn" system mounting with wall-mount plate
- Housing with simplified mounting system



FEATURES OF HOUSING





Material: ABS V0 as per UL94

Protection: IP20

Display: LCD 10 digits. Dimensions: 50 x 17 mm

Height of digits: Values: 10 mm; Units: 5 mm

Weight: 138 g

TECHNICAL FEATURES


Unit of measurement	ppm
Measuring range	From 0 to 5000 ppm
Accuracy*	±3% of reading ±50 ppm
Type of sensor	Infra-red sensor
Response time	T63 = 30 s
Resolution	1 ppm
Type of fluid	Air and neutral gases
Conditions of use (°C/%RH/m)	From 0 to +50°C. In non-condensing condition. From 0 to 2000 m.
Storage temperature	From -10 to +70°C

**All the accuracies indicated in this technical datasheet were stated in laboratory conditions, and can be guaranteed for measurements carried out in the same conditions, or carried out with calibration compensation.*

TECHNICAL SPECIFICATIONS


Output	1 RCR relay 3 A / 230 Vac Common mode voltage <30 VAC
Power supply	24 Vac/Vdc ±10%
Consumption	3 VA
Relay and alarm status	Red led in front and internal buzzer (70 dB at 10 cm)
European directives	2014/30/EU EMC; 2014/35/EU Low Voltage; 2011/65/EU RoHS II; 2012/19/EU WEEE
Electrical connection	Terminal block for cables Ø0.05 to 2.5 mm^2 Carried out according to the code of good practice
PC communication	USB-mini Din cable
Environment	Air and neutral gases

CONNECTIONS



ELECTICAL CONNECTIONS – as per *NFC15-100 standard*

This connection must be made by a qualified and trained technician. To make the connection, the transmitter must not be energized.



SETTINGS AND USE OF THE TRANSMITTER

➢ Thresholds configuration

The button allows to activate or not an alarm (threshold), to set the action of the alarm (edge), to set the threshold(s) value, to set the time-delay and to acknowledge the alarm.

Working principle:

- By pressing on the button more than 3 seconds, you can validate the setting and go to the next setting.
- By pressing quickly on the button, you can increment a value and scroll down the different option or values.

Setting procedure:

- **Activate or deactivate an alarm:**
  - ➢ Press on the button for 3 seconds, **"CONF"** is displayed then **"NEG"**, meaning that the relay is in negative security, it is excited during an alarm condition.
  - ➢ If needed, press quickly on the button to switch the relay in positive security, the relay is de-energized during an alarm condition or a current breaking, **"POS"** is displayed.

- Press 3 s on the button, **"Buzz"** screen is displayed with **"ON"** or **"OFF"** blinking. Briefly press on the button to activate (**"ON"**) or deactivate (**"OFF"**) (according to the last saved configuration) the buzzer during an alarm condition.
- Press 3 s on the button, **"Alarm"** screen is displayed with **"On"** or **"Off"** blinking (according to the last saved configuration).
- Press quickly on the button, the display changes from **"On" (activated alarm)** to **"Off" (deactivated alarm).**
- Press 3 s on the button to confirm the setting. If the alarm is deactivated, the instrument displays the measurement; if the alarm is activated, the instrument displays the following setting.

- **Set the action of the alarm (rising edge or falling edge)**


The edge determines the action of the alarm according to the trespassing direction of the threshold(s).

Mode Rising edge (1 threshold): the alarm goes off when the measurement **exceeds** the threshold and stops when it is **below** the threshold.

Mode Falling edge (1 threshold): the alarm goes off when the measurement is **below** the threshold and stops when it **exceeds** the threshold.


Mode Monitoring (2 thresholds): the alarm goes off when the measurement is outside the defined low and high thresholds.

Rising edge




Measurement (m) > Threshold (S) during the time-delay T1 ⟶ Alarm activation.
Measurement (m) < Threshold (S) - Hysteresis (H) during the time-delay T2 ⟶ Alarm deactivation.

Falling edge



Measurement (m) < Threshold (S) during the time-delayT1 ⟶ Alarm activation.
Measurement (m) > Threshold (S) + Hysteresis (H) during time-delay T2 ⟶ Alarm deactivation.

Monitoring



The alarm goes off when the measurement is outside the low and high thresholds.

- Press briefly on the button to select the trespassing direction then press the button more than 3 seconds to validate this direction and set the thresholds.

- **Set the threshold(s) value**

The first digit blinks, it corresponds to the positive (0) or negative (-) setting of the threshold value. Press briefly on the button to select the sign for the threshold value. Press on the button more than 3 seconds to validate.
The second digit blinks, press briefly on the button to scroll the numbers. Press the button more than 3 seconds to validate.
Repeat the process until the last digit to configure the threshold value, validate the threshold and go to the following setting.
If the monitoring edge has been selected, the transmitter displays the setting of the second threshold.

- **Set the hysteresis**

The hysteresis is only for the rising edge and the falling edge modes.
In rising edge mode, the hysteresis allows to the transmitter to stay in alarm when the measurement is between the threshold and the threshold minus the hysteresis.
Ex: for a 1000 ppm threshold and a 100 ppm hysteresis, the instrument will stay in alarm when the measurement will be between 1000 and 900 ppm.
In falling edge mode, the hysteresis allows to the transmitter to stay in alarm when the measurement is between the threshold and the threshold plus the hysteresis.
Ex: for a 1000 ppm threshold and a 100 ppm hysteresis, the instrument will stay in alarm when the measurement will be between 1000 and 1100 ppm.
The first digit blinks, set it pressing the button briefly several times then press on the button more than 3 seconds to set the following digit..
Once the hysteresis is set, press the button more than 3 seconds to validate and set the time-delays.

- **Set the time-delay 1 and the time-delay 2 (600 seconds maximum)**
  - In rising edge mode, the time-delay 1 corresponds to the time lag before the alarm goes off when the threshold has been reached. The time-delay 2, corresponds to the time lag before the alarm stops when the measurement is lower than the threshold minus the hysteresis.

Setting procedure: **"Time 1"** for the time-delay 1 is displayed then the time in second. The first digit blinks, press briefly on the button and scroll the figures. Press on the button more than 3 seconds to validate. Repeat the process until the last digit to set the time-delay 1 value (from 0 to 600 s) and validate. **"Time 2"** is displayed the time in second. Repeat the process to set the time-delay 2.

  - In falling edge mode, the time-delay 1 corresponds to the time lag before the alarm goes off when the threshold has been reached. The time-delay 2, corresponds to the time lag before the alarm stops when the measurement is lower than the threshold plus the hysteresis.

The setting procedure is the same as the rising edge procedure.

  - In monitoring mode, the alarm of the transmitter goes off when the measurement is below the lower threshold and higher the high threshold. The time-delay 1 corresponds to the time lag before the alarm goes off when the measurement is below the lower threshold and higher the high threshold. The time-delay 2 corresponds to the time lag before the alarm stops when the measurement is between the lower and higher thresholds.

The setting procedure is the same as the rising edge procedure.


The setting of time delays is done, the measurement is displayed.

CONFIGURATION VIA LCC-S SOFTWARE (option)

The software allows to set the alarms, the thresholds, and the time-delay of the instrument.

- To access the configuration via software :
  - Set the DIP switches as shown beside.
  - Connect the cable of the LCC-S to the connection of the transmitter.
- Please refer to the user manual of the LCC-S to make the configuration.


The configuration of the parameters can be done either with the DIP switch or via software (you can not combine both solutions)



MOUNTING

To mount the transmitter, mount the ABS plate on the wall (drilling: Ø6 mm, screws and pins are supplied).
Insert the transmitter on the fixing plate (see A on the drawing beside). Rotate the housing in clockwise direction until you hear a “click” which confirms that the transmitter is correctly installed.

Ambient model has not any fixing plate.
4 fixing holes are inside the back housing. Use them to install the transmitter on
the required location.



MAINTENANCE

Please avoid any aggressive solvent. Please protect the transmitter and its probes from any cleaning product containing formalin, that may be used for cleaning rooms or ducts.

OPTIONS AND ACCESSORIES

- **KIAL-100A:** power supply class 2, 230 Vac input, 24 Vac output
- **LCC-S:** configuration software with USB cable

Only the accessories supplied with the device must be used.

PRECAUTIONS FOR USE

Please always use the device in accordance with its intended use and within parameters described in the technical features in order not to compromise the protection ensured by the device.

FTang – CO2ST – 27/01/2017 – RCS (24) Périgueux 349 282 095 Non-contractual document – We reserve the right to modify the characteristics of our products without prior notice.

Once returned to KIMO, required waste collection will be assured in the respect of the environment in accordance with European guidelines relating to WEEE.

www.kimo.fr

Distributed by :

EXPORT DEPARTMENT
Tel : + 33. 1. 60. 06. 69. 25 - Fax : + 33. 1. 60. 06. 69. 29
e-mail : export@kimo.fr